

Inverting Operational Amplifier

Student Group

First Name	Surname	Matrikel Nr.

Table of Contents

Inverting Operational Amplifier 2
Gain of Op-Amp 2
Investigation of inverting input 3

Inverting Operational Amplifier

Gain of Op-Amp

Build the following circuit in [figure 1](#) with the power supply and a multimeter.



Fig. 1: Inverting Op-Amp

$U_{DD} = 10\text{ V}$, $U_{SS} = -10\text{ V}$, $R_1 = 10\text{ k}\Omega$

Calculate the necessary value for R_2 , so that the Output U_{OUT} is $+5\text{ V}$. Use the supply voltage of the operational amplifier for U_{IN} .

$U_{IN} =$

R_2

Investigation of inverting input



Fig. 2: Inverting Op-Amp: Investigate inverting input

$U_{DD} = 10\text{V}$, $U_{SS} = -10\text{V}$, $R_1 = 10\text{k}\Omega$

For U_{IN} , U_{OUT} , R_2 use the values from [figure 1](#).

Complete the arrows in the schematic of the circuit.

Determine the currents I_1 and I_2 indirectly through a voltage measurement.

Calculate the sum of the currents at Node_1 .

$$I_{\text{1}} \approx I_{\text{2}}$$
$$I_{\text{2}} \approx I_{\text{3}}$$
$$I_{\text{Sigma N1}} \approx I_{\text{Sigma N2}}$$

- Virt masse messen
- r2 kurzschluss

From:

<https://mexle.te.hs-heilbronn.de/> - MEXLE Wiki

Permanent link:

https://mexle.te.hs-heilbronn.de/lab05_en/inverting_op-amp_basics_amplification?rev=1775056475

Last update: **2026/04/01 17:14**

